
Soccer Net Installation Guide

Follow these steps to attach a replacement net to your soccer goal frame.

Before you begin

> **Do not wrap the net around the posts.** Secure it with ties or hook-and-loop fasteners.
>
> **The net is designed to stretch.**
>
> If the net does not line up, try rotating it 180 degrees.

Identify your goal's parts



Front frame

Two large vertical uprights connected by a horizontal crossbar.

Side bars

Two smaller supports connecting to the top and bottom of each upright. The upper side bars run back to a bend, then slants down to the ground as the rear support.

Ground bar

Connects the two bottom side bars along the ground at the back of the goal.

Installation steps

1. **Attach the top crossbar**

   Find the "Top Right" or "Top Left" tag and position it accordingly. Slightly stretch the net along the **crossbar**, fastening **every 8–12 inches**.

2. **Attach the front side uprights**

   Fasten the net down both **uprights** **every 8–12 inches**.

3 **Attach the upper side bars**

Gently stretch the net backward to each **upper side bar's** bend, approximately 3 feet behind the upright. Secure at four points per side: near the upright, at the bend, and at two evenly spaced points between them.

4 **Attach the bottom side bars**

Stretch and fasten the net along each **bottom side bar**, front to back, **every 8–12 inches**.

5 **Attach the rear supports**

Fasten along each slanted **rear support,** bottom to top, **every 8–12 inches**.

6 **Attach the ground bar**

Fasten **every 8–12 inches**.

Good to know: Some drooping between the upper side supports is normal, especially in the middle.

Need help?

First, confirm the net matches your goal. If it still won't fit, send us photos showing the net and how it's currently installed, and we'll help you troubleshoot. **customersupport@epicsports.com**